

CICLO - RAS03

01-04-2011

## SMOOTHING ON RESIN

Smoothing cycle on old resin coatings.


### Preparation of the substrate

The old resins coating must have strong adhesion to the substrate.

Choose the most convenient mechanical preparation: Grinding or Shot-Blasting.

### Application

1. Check that the old coating is solid everywhere and when not, remove the non-adhered parts. Replace them with **PAVIRAPID**.
2. Smoothing of the surface with **PAVIPLAST**, added with 1:0,8 of **Quarzo B1**, for a consumption of PAVIPLAST of around 0,40 kg/m<sup>2</sup>. Apply with an American trowel.
3. Smoothing of a second layer of **PAVIPLAST**, added with 1:0,8 of **Quarzo B0**, for a consumption of 0,35 kg/m<sup>2</sup>. of PAVIPLAST and 0,28 kg/m<sup>2</sup> of Quarzo B0. Apply with an American trowel.
4. Apply by roller a layer of **PAVIWATER**, diluted with 10% of water, for a consumption of around 0,130 kg/m<sup>2</sup>.
5. The joints must be cut and sealed with the poly-urethane elastomer **SIGILFLEX**.  
The final thickness of the resinous covering is around 1,0 mm.



### Products

PAVIRAPID A+B: fast drying epoxy mortar, to restore floors

PAVIPLAST A+B: self-levelling epoxy resin for high builds

PAVIWATER A+B: waterborne epoxy coating

SIGILFLEX: elastomer sealer

